



Assembly Instructions

OPRAH TABLE LAMP




Component Checklist

REF	A
PART	
NAME	Lamp Base
QTY	1

Putting Me Together

WARNING: Make sure the lamp is unplugged from the wall socket lamp while changing bulbs.



- ① Place Lamp Base (A) on a flat surface.
- ② Install a light bulb (not included) into the socket on lamp base (A), turn counter clockwise to tighten securely.

- ③ Insert the plug into your wall socket, turn on the switch and enjoy your Oprah Table Lamp!

220-240V-50Hz E14 Max. 40W

Bulb not included