


Edgar External Wall Light Installation Instructions

Code	Description	Colour	Wattage
5505130	Edgar External Wall Light - 60cm - Black	Black	12w
5505131	Edgar External Wall Light - 60cm - White	White	12w
5505132	Edgar External Wall Light - 100cm - Black	Black	26w
5505133	Edgar External Wall Light - 100cm - White	White	26w
5505134	Edgar External Wall Light - 150cm - Black	Black	34w
5505135	Edgar External Wall Light - 150cm - White	White	34w



Important Safety Issues:

- This product must be installed by a professional, licensed electrician according to AS/NZ 3000.
- Ensure power supply is switched off before installation
- Modifications of this product will void any warranty
- Vencha Lighting does not take responsibility for wrong installation or incorrect use.

Steps for Installation:

1. Turn off power, make sure circuit is free of voltage.
2. Remove mounting bracket from wall light.
3. Secure bracket on ceiling in desired location that is capable of supporting product.
4. Connect fitting to appropriate power source.
5. Select desired light colour from 3CCT switch, place fitting back on bracket and secure tightly ensuring product maintains waterproof rating.
6. Once installation is complete, turn power back on and test fitting operates correctly

